

Effective: April 15, 2006
Supersedes: April 15, 2003

OPERATION, SAFETY & PROCEDURE GUIDELINE MANUAL

FOR

RUB-R-WALL® AIRTIGHT **AIR/VAPOR BARRIER**

as manufactured by

Rubber Polymer Corporation
1135 West Portage Trail Ext.
Akron, OH 44313-8283 USA

Toll Free Telephone (US & Canada): 1.800.860.7721
Direct Telephone: 330.945.7721* Fax Line: 330.945.9416

Website: www.rpcinfo.com
General E-mail: sales@rpcinfo.com

OPERATION, SAFETY & PROCEDURE
GUIDELINE MANUAL
FOR

RUB-R-WALL® AIRTIGHT AIR/VAPOR BARRIER

IMPORTANT INFORMATION

Rub-R-Wall Airtight is 100% rubber polymer. That makes it tougher and stronger than asphalt based competitive products.

The Rub-R-Wall Airtight membrane meets Federal, State and many Local VOC emission requirements.

In its cured state on the wall, Rub-R-Wall Airtight is solvent-free, non-toxic and non-carcinogenic. However, in its liquid, uncured form, Rub-R-Wall Airtight contains solvents that are **flammable and hazardous**. Because of this, Rub-R-Wall Airtight is not to be used in confined spaces and should only be used in areas which are well-ventilated. If Rub-R-Wall Airtight is used or stored in a poorly ventilated area, there is a risk that the flammable vapors will accumulate and create a potentially explosive environment.

Therefore, it is important that you do not store, transport or apply Rub-R-Wall Airtight before reading and understanding the Material Safety Data Sheet (MSDS) and safety/application information presented on the following pages.

If you do not understand any of this information we urge you to call us with your questions, toll free at 1.800.860.7721, or direct at 330.945.7721.

Note: The information presented here by RPC, Inc. is not able to, or intended to, supplant individual training, responsibility or judgment of the user.

SECTION 1: SAFETY INFORMATION

1. DO NOT spray Rub-R-Wall® Airtight before reading and understanding the following safety guideline and the Rub-R-Wall Airtight MSDS. If you need additional copies of the MSDS, please contact us and we will forward more immediately. A copy of the Rub-R-Wall Airtight MSDS is attached to the back of this manual. You can also find copies affixed to each barrel of material shipped to you.
2. DO NOT spray Rub-R-Wall Airtight without being adequately trained in the operation and safety of your company's application equipment and have read and understand the instructions provided by the manufacturer of the application equipment.
3. DO NOT SPRAY ALONE.
4. DO NOT spray indoors or in confined spaces. Spraying or otherwise applying Rub-R-Wall Airtight or its related products in confined spaces is an inherently dangerous activity and could result in a fire and/or explosion. DO NOT attempt to apply such products in confined spaces, basements or crawlspaces.
5. Approved heatable tanks, if used, should be vented in accordance with the tank manufacturer's specifications and instructions. The temperature in the tank should be maintained at a level that will give 130°F to 150°F temperatures at the tip of the spray gun.
6. When pouring into a heatable tank, ALWAYS ground barrel to tank...tank to truck...truck to ground. Always ground both containers when pouring Rub-R-Wall Airtight. This ground must be attached to link both containers. Transferring Rub-R-Wall Airtight must be done in a well ventilated area away from sparks, flames, and any ignition sources.
7. DO NOT heat Rub-R-Wall Airtight above 160°F. Properly vent the top of the barrel by loosening the bungs. If barrel heaters are used, the barrels must be properly vented to the outdoors. This prevents the accumulation of solvent vapors in confined areas while allowing for the expansion of heated materials. Always follow the safety and operational instructions provided by the manufacturers of the barrel heaters.
8. Enclosed application trucks or vans must have proper ventilation or air movement to avoid air pocket accumulations of dangerous or explosive fumes or vapors.

9. Store and transport Rub-R-Wall® Airtight according to Local, State, Federal, Fire, D.O.T and environmental codes. For further information call the appropriate authority in your area. This also applies to storage, transportation and disposal of empty Rub-R-Wall Airtight barrels.
10. Secure the job site by posting no smoking signs. Keep all sources of ignition away from Rub-R-Wall Airtight material and vapors. DO NOT smoke around Rub-R-Wall Airtight barrels, equipment, or on application sites. Be certain other contractors are aware of the flammability of the product and ignition sources on the job site. DO NOT spray near pilot lights or active electrical switches or devices.
11. DO NOT breathe vapors. Applicators and others subjected to fumes are required to wear NIOSH approved disposable organic vapor respirators. Medical approval must be obtained for each person who will require a mask. Proper individual fit is required. Displacement of air by solvent vapors can lead to oxygen deprivation causing dizziness, unconsciousness, or death. High vapor concentration can overwhelm the filters in the masks. If you detect fumes through the mask or feel lightheaded or dizzy, move to a fresh air area immediately. Make sure your mask filter cartridges are functioning properly, if not, replace them.
12. High pressure airless sprayers are potentially dangerous. Direct spray can penetrate skin or eyes and cause serious injury. If accidental penetration occurs seek medical attention immediately.
13. Prior to commencement of spray application, properly ground truck to a copper grounding rod. ALL VEHICLES MUST BE GROUNDED.
14. Wear gloves, cap, and coveralls to prevent skin contact.
15. Wear safety goggles with side shields. If Rub-R-Wall Airtight gets into eyes, flush with clean water. Seek immediate medical attention with a copy of the MSDS.
16. OSHA regulations require a working fire extinguisher and first aid kit in the truck cab. Fire extinguishers should be located near all truck doors, and an extinguisher should also be accessible at the spray site.
17. All Rub-R-Wall Airtight barrels, whether full or empty, should be stored in protected areas. Keep them away from children. These containers are hazardous when emptied. Emptied containers retain vapors and liquid. All hazard precautions must be observed when handling emptied containers. Empty drums are not suitable for use as trash containers, rafts, barbeque pits or any similar use.

SECTION 2: INSTALLATION PROCEDURES

1. Rub-R-Wall® Airtight is designed to be installed in the cavity wall. It is not intended to be used for interior application.
2. DO NOT apply Rub-R-Wall Airtight over asphalt or tar based products. Rub-R-Wall Airtight may be applied over self adhering rubberized asphalt membranes, and conversely, may be applied on top of Rub-R-Wall Airtight.
3. DO NOT apply Rub-R-Wall Airtight when the ambient temperature is below 15°F.
4. DO NOT apply Rub-R-Wall Airtight to frozen surfaces that have not had a chance to cure. Poured concrete walls, mortar, masonry block cores filled with concrete as well as parged surfaces must be cured before applying Rub-R-Wall Airtight.
5. DO NOT introduce any material that will enhance or dilute Rub-R-Wall Airtight. This will adversely affect its characteristics. DO NOT thin Rub-R-Wall Airtight.
6. GROUND THE TRUCK, barrels and all spray equipment to the ground at the jobsite. The rig must always be grounded while spraying, no exceptions.
7. Post a no smoking sign, and be sure that no other tradesmen introduce any ignition sources during your time at the jobsite; welding, smoking, electrical equipment, etc.
8. Proceed to apply the waterproofing membrane; application should be made in multiple, uniform passes such that a wet membrane thickness of 60-80 mils is obtained as determined by a standard mil gauge. A cured thickness of 30-40 mils will result. Spraying a tack coat first will help eliminate sags and runs.
9. Rub-R-Wall Airtight membrane should be firm after 15-20 minutes.
10. Rub-R-Wall Airtight is not intended as a permanently exposed membrane. It should be covered within 30 days.

SECTION 3: EQUIPMENT

1. Rub-R-Wall® Airtight is to be heated to a temperature range of 130-150°F (at the spray tip) for installation. The spray pump should be able to achieve an input pressure of 3000 psi for Rub-R-Wall Airtight application.
2. Rub-R-Wall Airtight can be heated through a single pass heat exchanger connected to an engine's coolant system, or band heaters applied to Rub-R-Wall Airtight barrels. Rub-R-Wall Airtight temperature should never exceed 160°F.
3. Graco 45:1 airless spray pumps are recommended (or comparable unit).
4. Interlinking lines between the pump, heat exchanger and the material, should be short, and have a larger diameter, to ensure good material flow. Lines should not exceed 4 feet in length, and the diameter should be at least 2 inches.
5. A high pressure spray hose is required, with a diameter of no more than 1/2 inch, and a length of no more than 200 feet.
6. Graco Silver Plus spray gun, with spray tip .631 (oval opening shape) is recommended.
7. All connections should be as tight as possible, as to not introduce air leaks.

For further questions contact:

Rubber Polymer Corporation Inc.
1135 West Portage Trail Ext.
Akron, Ohio 44313
800.860.7721

Note: The information presented here by RPC, Inc. is not able to, or intended to, supplant individual training, responsibility or judgment of the user.

